## dium

## **INSTALLATION INSTRUCTIONS**

FUEL FILTER MOUNT TOYOTA MK5 SUPRA

**Document:** 19-0275

Support: info@radiumauto.com

## **CAUTION**

Only a qualified technician following applicable safety procedures should perform the installation of this product. One must have knowledge in repair and modification of fuel systems and general vehicle modifications to install this product.

Gasoline and other fuels are flammable and can be explosive.

Only install in a well-ventilated location to minimize buildup of fuel vapors.

No sparks, open flames, smoking or other ignition sources are to be present. Draining and removal of all fuel from the fuel system is recommended.

Proper eye and personal protection is required at all times during installation.

## WARNING

The fuel system is under pressure! Do not loosen any connections until relieving the fuel system pressure.

Consult a service manual for instructions on relieving fuel pressure safely. This product is designed for off-highway and racing use only. Fuel system components may not be legal for sale or use on emissions controlled motor vehicles. Consult local, state, and federal laws.

| STEP | TOOLS NEEDED                                  | INSTRUCTIONS  | РНОТО  |
|------|---|---|--|
| 1    | Car Lift 8mm Socket Wrench 10mm Socket Wrench | Disconnect the battery and depressurize the fuel system.  The fuel filter will be mounted underneath to the LH side of the transmission. Safely raise the vehicle. Dislodge the rear undercarriage panels.  |  |
| 2    | 10mm Wrench                                   | Insert the upper fuel filter mount through the two studs.  As shown, secure the upper filter mount using the provided M6x1mm nuts.  |  |
| 3    | 4mm Allen Wrench Thread Locker                | NOTE: The fuel filter mount is compatible with inline Radium Engineering fuel filters (not included).  Orient the fuel filter specific to your vehicle. Line up the lower filter mount to the upper filter mount. Secure the filter using the provided M5x0.8mm socket head screws and medium strength thread locker. |  |
| 4    | 10mm Socket Wrench                            | Reinstall all OEM components in reverse order.  INSTALLATION COMPLETE   | ENEW CONTROL OF THE PARTY OF TH |